## 6.31 ALARM 941 (INCORRECTLY INSTALLED MEMORY PRINTED-CIRCUIT BOARD)

Cause and corrective action

This alarm indicates the poor connection of a memory printed–circuit board. Check that all connections are secure.

## NOTE

This alarm will not occur during ordinary operation. It is most likely to occur when a printed–circuit board is pulled out and inserted again, or replaced, for maintenance purposes, for example.

Ensure that all printed-circuit boards are installed securely.

If this alarm occurs even when the memory printed–circuit boards are installed securely, replace the master and memory printed–circuit boards.